



# UltraClean<sup>®</sup> Microbial DNA Isolation Kit

Catalog No.	Quantity
12224-50	50 Preps
12224-250	250 Preps

## *Instruction Manual*

New protocol instruction: *Shake Solution MD3 to mix before using to ensure consistent results.*



Please recycle



## Table of Contents

Introduction .....	3
Protocol Overview.....	3
Flow Chart.....	4
Equipment Required .....	5
Kit Contents & Storage .....	5
Precautions & Warnings .....	5
Protocols:	
Experienced User Protocol.....	6
Detailed Protocol (Describes what is happening at each step) .....	7
Vacuum Manifold Protocol .....	10
Hints & Troubleshooting Guide .....	12
Contact Information. ....	13
Other Quality Products Available .....	14



## Introduction

The UltraClean<sup>®</sup> Microbial DNA Isolation Kit is designed to isolate high-quality genomic DNA from microorganisms. A variety of microorganisms, including bacterial and fungal spores, have been tested successfully with this kit.

## Protocol Overview

Microbial cells, resuspended in bead solution are added to a bead beating tube containing beads, followed by lysis solution. The principal is to lyse the microorganisms by a combination of heat, detergent, and mechanical force against specialized beads. The cellular components are lysed by mechanical action using a specially designed MO BIO Vortex Adapter on a standard vortex. From the lysed cells, the released DNA is bound to a silica Spin Filter. The filter is washed, and the DNA is recovered in certified DNA-free Tris buffer.


## High Throughput Options

MO BIO offers a vacuum based protocol for faster processing without centrifugation for the DNA binding and column washing steps for Spin Filters. The MO BIO PowerVac<sup>™</sup> Manifold allows for processing of up to 20 spin filter preps at a time using the PowerVac<sup>™</sup> Mini Spin Filter Adapters. The UltraClean<sup>®</sup>-htp 96 Well Microbial DNA Isolation Kit is available for processing up to 2 x 96 samples using a centrifuge capable of spinning two 96 Well Blocks stacked (13 cm x 8 cm x 5.5 cm) at 2500 x g. For 96 well homogenization of bacteria, MO BIO offers the 96 Well Plate Shaker and Plate Adapter Set (MO BIO Catalog# 11996 & 11999, respectively.)

**This kit is for research purposes only. Not for diagnostic use.**

Other Related Products	Catalog No.	Quantity
UltraClean <sup>®</sup> Microbial RNA Isolation Kit	15800-50	50 preps
	15800-250	250 preps
UltraClean <sup>®</sup> PCR Clean-Up Kit	12500-50	50 preps
	12500-100	100 preps
	12500-250	250 preps
UltraClean <sup>®</sup> -htp 96 Well Microbial DNA Isolation Kit	10196-4	4 x 96 preps
	10196-12	12 x 96 preps
PowerVac <sup>™</sup> Manifold	11991	1 manifold
PowerVac <sup>™</sup> Mini System	11992	1 unit + 20 adapters
PowerVac <sup>™</sup> Mini Spin Filter Adapters	11992-10	10 adapters
	11992-20	20 adapters

## UltraClean<sup>®</sup> Microbial DNA Isolation Kit





## Equipment Required

Microcentrifuge (10,000 x g)

Pipettor (50 µl – 200 µl, 100 µl – 1000 µl)

Vortex-Genie<sup>®</sup> 2 Vortex (MO BIO Catalog# 13111-V or 13111-V-220)

Vortex Adapter (MO BIO Catalog# 13000-V1)

## Reagents Required but not Included

100% ethanol (for the PowerVac<sup>™</sup> Manifold protocol only)

## Kit Contents

Component	Kit Catalog # 12224-50		Kit Catalog # 12224-250	
	Catalog #	Amount	Catalog #	Amount
MicroBead Tubes (contain 250 mg MicroBeads)	12224-50-BT	50	12224-250-BT	250
MicroBead Solution	12224-50-BS	16.5 ml	12224-250-BS	80 ml
Solution MD1	12224-50-1	2.75 ml	12224-250-1	15 ml
Solution MD2	12224-50-2	5.5 ml	12224-250-2	30 ml
Solution MD3	12224-50-3	50 ml	12224-250-3	250 ml
Solution MD4	12224-50-4	16.5 ml	12224-250-4	3 x 32 ml
Solution MD5	12224-50-5	3 ml	12224-250-5	15 ml
Spin Filters Units in 2 ml Tubes	12224-50-SF	50	12224-250-SF	250
2 ml Collection Tubes	12224-50-T	200	12224-250-T	1000

## Kit Storage

Kit reagents and components should be stored at room temperature (15-30°C).

## Precautions

Please wear gloves when using this product. Avoid all skin contact with kit reagents. In case of contact, wash thoroughly with water. Do not ingest. See Material Safety Data Sheets for emergency procedures in case of accidental ingestion or contact. All MSDS information is available upon request (760-929-9911) or at [www.mobio.com](http://www.mobio.com). Reagents labeled flammable should be kept away from open flames and sparks.

**WARNING:** Solution MD4 contains ethanol, it is flammable. Do not use bleach to clean the inside of the PowerVac<sup>™</sup> Manifold or to rinse the PowerVac<sup>™</sup> Mini Spin Filter Adapters when attached to the manifold.

**IMPORTANT NOTE FOR USE:** Make sure the 2 ml MicroBead Tubes rotate freely in the centrifuge without rubbing. Do not spin the MicroBead Tubes in excess of 10,000 x g. Shake to mix Solution MD3 before use.



## Experienced User Protocol

(If this is your first time using this kit please read the Detailed Protocol on the following page)

Please wear gloves at all times

1. Add 1.8 ml of microbial (bacteria, yeast) culture to a **2 ml Collection Tube** (provided) and centrifuge at 10,000 x *g* for 30 seconds at room temperature. Decant the supernatant and spin the tubes at 10,000 x *g* for 30 seconds at room temperature and completely remove the media supernatant with a pipette tip. **NOTE:** Based on the type of microbial culture, it may be necessary to centrifuge longer than 30 seconds.
2. Resuspend the cell pellet in 300  $\mu$ l of **MicroBead Solution** and gently vortex to mix. Transfer resuspended cells to **MicroBead Tube**.
3. Check **Solution MD1**. If **Solution MD1** is precipitated, heat the solution at 60°C until the precipitate has dissolved. Add 50  $\mu$ l of **Solution MD1** to the **MicroBead Tube**.
4. **Optional:** To increase yields, to minimize DNA shearing, or for difficult cells, see Alternative lysis methods in the "Hints & Troubleshooting Guide" section before continuing.
5. Secure **MicroBead Tubes** horizontally using the MO BIO Vortex Adapter tube holder for the vortex (MO BIO Catalog# 13000-V1) or secure tubes horizontally on a flat-bed vortex pad with tape. Vortex at maximum speed for 10 minutes. (See "Hints & Troubleshooting Guide" for less DNA shearing).
6. Make sure the 2 ml **MicroBead Tubes** rotate freely in the centrifuge without rubbing. Centrifuge the tubes at 10,000 x *g* for 30 seconds at room temperature. **CAUTION:** Be sure not to exceed 10,000 x *g* or tubes may break.
7. Transfer the supernatant to a clean **2 ml Collection Tube** (provided).
8. **NOTE:** Expect 300 to 350  $\mu$ l of supernatant.
9. Add 100  $\mu$ l of **Solution MD2**, to the supernatant. Vortex for 5 seconds. Then incubate at 4°C for 5 minutes.
10. Centrifuge the tubes at room temperature for 1 minute at 10,000 x *g*.
11. Avoiding the pellet, transfer the entire volume of supernatant to a clean **2 ml Collection Tube** (provided). Expect approximately 450  $\mu$ l in volume.
12. Shake to mix **Solution MD3** before use. Add 900  $\mu$ l of **Solution MD3** to the supernatant and vortex for 5 seconds.
13. Load about 700  $\mu$ l into the **Spin Filter** and centrifuge at 10,000 x *g* for 30 seconds at room temperature. Discard the flow through, add the remaining supernatant to the **Spin Filter**, and centrifuge at 10,000 x *g* for 30 seconds at room temperature. **NOTE:** A total of 2 to 3 loads for each sample processed are required. Discard all flow through liquid.
14. Add 300  $\mu$ l of **Solution MD4** and centrifuge at room temperature for 30 seconds at 10,000 x *g*.
15. Discard the flow through.
16. Centrifuge at room temperature for 1 minute at 10,000 x *g*.
17. Being careful not to splash liquid on the spin filter basket, place **Spin Filter** in a new **2 ml Collection Tube** (provided).
18. Add 50  $\mu$ l of **Solution MD5** to the center of the white filter membrane.
19. Centrifuge at room temperature for 30 seconds at 10,000 x *g*.
20. Discard **Spin Filter**. The DNA in the tube is now ready for any downstream application. No further steps are required.

We recommend storing DNA frozen (-20°C). **Solution MD5** contains no EDTA.

Thank you for choosing the UltraClean<sup>®</sup> Microbial DNA Isolation Kit.



## Detailed Protocol (Describes what is happening at each step)

Please wear gloves at all times

1. Add 1.8 ml of microbial (bacteria, yeast) culture to a **2 ml Collection Tube** (provided) and centrifuge at 10,000 x g for 30 seconds at room temperature. Decant the supernatant and spin the tubes at 10,000 x g for 30 seconds at room temperature and completely remove the media supernatant with a pipette tip.

*What's happening: This step concentrates and pellets the microbial cells. In some cases it may take longer to completely pellet the cells. It is important to pellet the cells completely and remove all the culture media in this step.*

2. Resuspend the cell pellet in 300 µl of **MicroBead Solution** and gently vortex to mix. Transfer resuspended cells to **MicroBead Tube**.

*What's happening: The MicroBead Solution contains salts and a buffer which stabilizes and homogeneously disperses the microbial cells prior to lysis.*

3. Check **Solution MD1**. If **Solution MD1** is precipitated, heat the solution at 60°C until the precipitate has dissolved. Add 50 µl of **Solution MD1** to the **MicroBead Tube**.

*What's happening: Solution MD1 contains SDS and other disruption agents required for cell lysis. In addition to aiding in cell lysis, SDS is an anionic detergent that breaks down fatty acids and lipids associated with the cell membrane of several organisms. If it gets cold, it will precipitate. Heating at 60°C will dissolve the SDS and will not harm the SDS or the other disruption agents. In addition, Solution MD1 can be used while it is still warm.*

4. **Optional:** To increase yields, to minimize DNA shearing, or for difficult cells, see Alternative lysis methods in the "Hints & Troubleshooting Guide" section before continuing.

*What's happening: This optional step can lead to better performance in some cases. We recommend using only one of these methods for any individual prep.*

5. Secure **MicroBead Tubes** horizontally using the MO BIO Vortex Adapter tube holder for the vortex (MO BIO Catalog# 13000-V1) or secure tubes horizontally on a flat-bed vortex pad with tape. Vortex at maximum speed for 10 minutes. (See "Hints & Troubleshooting Guide" for less DNA shearing).

*What's happening: This step creates the combined chemical/ mechanical lysis conditions required to release desired nucleic acids from microbial cells. Many cell types will not lyse without this chemically enhanced bead beating process. The vortex action is typically all that is required, however, more robust bead beaters may also be used. In most cases the times may be shorter with other devices but you may run the risk of increased DNA shearing. This process is compatible with fast prep machines.*

6. Make sure the 2 ml **MicroBead Tubes** rotate freely in the centrifuge without rubbing. Centrifuge the tubes at 10,000 x g for 30 seconds at room temperature. **CAUTION:** Be sure not to exceed 10,000 x g or tubes may break.

*What's happening: The cell debris is sent to the bottom of the tube while DNA is remains in the supernatant.*

7. Transfer the supernatant to a clean **2 ml Collection Tube** (provided).



8. **NOTE:** Expect 300 to 350  $\mu\text{l}$  of supernatant.

*What's happening: The volume to expect will vary depending on the size of the original cell pellet from step 1.*

9. Add 100  $\mu\text{l}$  of **Solution MD2**, to the supernatant. Vortex for 5 seconds. Then incubate at 4°C for 5 minutes.
10. Centrifuge the tubes at room temperature for 1 minute at 10,000 x g.

*What's happening: Solution MD2 contains a reagent to precipitate non-DNA organic and inorganic material including cell debris and proteins. It is important to remove contaminating organic and inorganic matter that may reduce DNA purity and inhibit downstream DNA applications.*

11. Avoiding the pellet, transfer the entire volume of supernatant to a clean **2 ml Collection Tube** (provided). Expect approximately 450  $\mu\text{l}$  in volume.

*What's happening: The pellet at this point contains non-DNA organic and inorganic materials, including cell debris and proteins. For the best DNA quality and yield, avoid transferring any of the pellet.*

12. Shake to mix Solution MD3 before use. Add 900  $\mu\text{l}$  of **Solution MD3** to the supernatant and vortex for 5 seconds.

*What's happening: Solution MD3 is a highly concentrated salt solution. It sets up the high salt condition necessary to bind DNA to the Spin Filter membrane in the following step.*

13. Load about 700  $\mu\text{l}$  into the **Spin Filter** and centrifuge at 10,000 x g for 30 seconds at room temperature. Discard the flow through, add the remaining supernatant to the **Spin Filter**, and centrifuge at 10,000 x g for 30 seconds at room temperature. **NOTE:** A total of 2 to 3 loads for each sample processed are required. Discard all flow through liquid.

*What's happening: DNA is selectively bound to the silica membrane in the Spin Filter device. Contaminants pass through the filter membrane, leaving only the DNA bound to the membrane.*

14. Add 300  $\mu\text{l}$  of **Solution MD4** and centrifuge at room temperature for 30 seconds at 10,000 x g.

*What's happening: Solution MD4 is an ethanol based wash solution used to further clean the DNA that is bound to the silica filter membrane in the Spin Filter. This wash solution removes residues of salt, and other contaminants while allowing the DNA to stay bound to the silica membrane.*

15. Discard the flow through.

*What's happening: This flow through is waste containing ethanol wash solution and contaminants that did not bind to the silica Spin Filter membrane.*

16. Centrifuge at room temperature for 1 minute at 10,000 x g.

*What's happening: This step removes residual Solution MD4 (ethanol wash solution). It is critical to remove all traces of wash solution because it can interfere with down stream DNA applications.*

17. Being careful not to splash liquid on the spin filter basket, place **Spin Filter** in a new **2 ml Collection Tube** (provided).





*What's happening: It is important to avoid any traces of the ethanol based wash solution.*

18. Add 50  $\mu$ l of **Solution MD5** to the center of the white filter membrane.

*What's happening: Placing the Solution MD5 (elution buffer) in the center of the small white membrane will make sure the entire membrane is wetted. This will result in more efficient release of bound DNA*

19. Centrifuge at room temperature for 30 seconds at 10,000 x g.

*What's happening: As the Solution MD5 (elution buffer) passes through the silica membrane, DNA is released, and it flows through the membrane, and into the Collection Tube. The DNA is released because it can only bind to the silica Spin Filter membrane in the presence of salt. Solution MD5 is 10mM Tris pH 8 and does not contain salt.*

20. Discard **Spin Filter**. DNA in the tube is now ready for any downstream application. No further steps are required.

We recommend storing DNA frozen (-20°C). **Solution MD5** contains no EDTA.

**Thank you for choosing the UltraClean<sup>®</sup> Microbial DNA Isolation Kit.**



## Vacuum Protocol using the PowerVac™ Manifold

Please wear gloves at all times

For each sample lysate, use one Spin Filter column. Keep the Spin Filter in the attached 2 ml Collection Tube and continue using the Collection Tube as a Spin Filter holder until needed for the Vacuum Manifold Protocol. Label each Collection Tube top and Spin Filter column to maintain sample identity. If the Spin Filter becomes clogged during the vacuum procedure, you can switch to the procedure for purification of the DNA by centrifugation.

You will need to provide 100% ethanol for step 4 of this protocol

1. For each prep, attach one aluminum **PowerVac™ Mini Spin Filter Adapter** (MO BIO Catalog# 11992-10 or 11992-20) into the Luer-Lok® fitting of one port in the manifold. Gently press a Spin Filter column into the PowerVac™ Mini Spin Filter Adapter until snugly in place. Ensure that all unused ports of the vacuum manifold are closed.  
**Note:** Aluminum PowerVac™ Mini Spin Filter Adapters are reusable.
2. Transfer 650 µl of prepared sample lysate (from step 12) to the **Spin Filter column**.
3. Turn on the vacuum source and open the stopcock of the port. Hold the tube in place when opening the stopcock to keep the spin filter steady. Allow the lysate to pass through the **Spin Filter column**. After the lysate has passed through the column completely, load again with the next 650 µl of lysate. Continue until all of the lysate has been loaded onto the **Spin Filter column**. Close the one-way Luer-Lok® stopcock of that port.  
**Note:** If Spin Filter Columns are filtering slowly, close the ports to samples that have completed filtering to increase the pressure to the other columns.
4. Load 800 µl of 100% ethanol into the Spin Filter so that it completely fills the column. Open the stopcock while holding the column steady. Allow the ethanol to pass through the column completely. Close the stopcock.
5. Add 300 µl of **Solution MD4** to each Spin Filter. Open the Luer-Lok® stopcock and apply a vacuum until **Solution MD4** has passed through the Spin Filter completely. Continue to pull a vacuum for another minute to dry the membrane. Close each port.
6. Turn off the vacuum source and open an unused port to vent the manifold. If all 20 ports are in use, break the vacuum at the source. Make certain that all vacuum pressure is released before performing the next step. It is important to turn off the vacuum at the source to prevent backflow into the columns.
7. Remove the **Spin Filter column** and place in the original labeled **2 ml Collection Tube**. Place into the centrifuge and spin at 13,000 × g for 1 minute to completely dry the membrane.
8. Transfer the **Spin Filter column** to a new **2 ml Collection Tube** and add 50 µl of **Solution MD5** to the center of the white filter membrane. Alternatively, sterile DNA-Free PCR Grade Water may be used for elution from the silica **Spin Filter** membrane at this step (MO BIO Catalog# 17000-10).
9. Centrifuge at room temperature for 30 seconds at 10,000 × g.



10. Discard the **Spin Filter column**. The DNA in the tube is now ready for any downstream application. No further steps are required.

We recommend storing DNA frozen (-20° to -80°C). **Solution MD5** contains no EDTA. To concentrate the DNA see the Hints & Troubleshooting Guide.

**Thank you for choosing the UltraClean<sup>®</sup> Microbial DNA Isolation Kit.**



## Hints and Troubleshooting Guide

**Alternative Lysis Methods** (*We recommend using only one of these methods for any individual prep.*)

- **To increase yields:** Heating can aid in lysis for some organisms and it can lead to increased yields. Heat preps at 65°C for 10 minutes and continue with step 5.
- **For less DNA shearing:** We recommend heating the preps at 65°C for 10 minutes with occasional bump vortexing for a few seconds every 2-3 minutes. Skip step 5 and go to step 6. This helps prevent unwanted damage to large DNA. This procedure will reduce DNA shearing and at the same time can increase the yield of total DNA for some organisms.
- **If cells are difficult to lyse:** Heat the preps at 70°C for 10 minutes. Follow by continuing with the protocol at step 5.

### **Concentrating the DNA**

The final volume of eluted DNA will be 50 µl. The DNA may be concentrated by adding 5 µl of 5M NaCl and inverting 3-5 times to mix. Next, add 100 µl of 100% cold ethanol and invert 3-5 times to mix. Incubate at -20°C for 30 minutes and centrifuge at 10,000 x g for 15 minutes at room temperature. Decant all liquid. Remove residual ethanol in a speed vac or dessicator or air dry. Resuspend precipitated DNA in sterile water or Solution MD5 (10 mM Tris).

### **DNA Floats Out of Well When Loaded on a Gel**

This usually occurs because residual Solution MD4 remains in the final sample. Prevent this by being careful in step 17 not to transfer liquid onto the bottom of the spin filter basket. Ethanol precipitation (described in "Concentrating the DNA") is the best way to remove residual Solution MD4.

### **Storing DNA**

DNA is eluted in Solution MD5 (10 mM Tris) and must be stored at -20°C to -80°C to prevent degradation. For long term storage, we recommend aliquoting DNA into appropriate volumes and store at -80°C. DNA can be eluted in TE without loss, but the EDTA may inhibit downstream reactions such as PCR and automated sequencing. DNA may also be eluted with sterile DNA-Free PCR Grade Water (MO BIO Catalog# 17000-10).

### **Cleaning of the PowerVac™ Mini Spin Filter Adapters**

It is recommended to rinse the PowerVac™ Mini Spin Filter Adapters promptly after use to avoid salt build up. To clean the PowerVac™ Mini Spin Filter Adapters, rinse each adapter with DI water followed by 70% ethanol and flush into the manifold base. Alternatively, remove the adapters and wash in laboratory detergent and DI water. PowerVac™ Mini Spin Filter Adapters may be autoclaved.

**Do not use bleach to clean the PowerVac™ Mini Spin Filter Adapters while attached to the PowerVac™ Manifold. Bleach should never be mixed with solutions containing guanidine and should not be used to clean the PowerVac™ Manifold. For more information on cleaning the PowerVac™ Manifold, please refer to the PowerVac™ Manifold manual.**



## Contact Information

### Technical Support:

Phone MO BIO Laboratories, Inc. Toll Free 800-606-6246, or 760-929-9911

Email: [technical@mobio.com](mailto:technical@mobio.com)

Fax: 760-929-0109

Mail: MO BIO Laboratories, Inc, 2746 Loker Ave West, Carlsbad, CA 92010

### Ordering Information:

Direct: Phone MO BIO Laboratories, Inc. Toll Free 800-606-6246, or 760-929-9911

Email: [orders@mobio.com](mailto:orders@mobio.com)

Fax: 760-929-0109

Mail: MO BIO Laboratories, Inc, 2746 Loker Ave West, Carlsbad, CA 92010

For the distributor nearest you, visit our web site at [www.mobio.com/distributors](http://www.mobio.com/distributors)



## Other Quality Products Available from MO BIO Laboratories, Inc.

For more product and detailed information go to [www.mobio.com/catalog-request](http://www.mobio.com/catalog-request) to request a catalog.

DNA Purification and Gel Extraction	Catalog No.	Quantity
PowerClean® DNA Clean-Up Kit	12877-50	50 preps
UltraClean® 15 DNA Purification Kit	12100-300	300 preps
UltraClean® PCR Clean-Up Kit	12500-50 12500-100 12500-250	50 preps 100 preps 250 preps
UltraClean®-htp 96 Well PCR Clean-Up Kit	12596-4 12596-12	4 x 96 preps 12 x 96 preps
UltraClean® GelSpin® DNA Extraction Kit	12400-50 12400-100 12400-250	50 preps 100 preps 250 preps
Plasmid DNA Isolation	Catalog No.	Quantity
UltraClean® 6 Minute Mini Plasmid Prep Kit	12300-50 12300-100 12300-250	50 preps 100 preps 250 preps
UltraClean® Standard Mini Plasmid Prep Kit	12301-50 12301-100 12301-250	50 preps 100 preps 250 preps
UltraClean®-htp 96 Well Plasmid Prep Kit	12396-4 12396-12	4 x 96 preps 12 x 96 preps
UltraClean® Midi Plasmid Prep Kit	12700-20 12700-50	20 preps 50 preps
UltraClean® Maxi Plasmid Prep Kit	12600-10 12600-20	10 preps 20 preps
UltraClean® Endotoxin-Free Mini Plasmid Prep Kit	12311-100 12311-250	100 preps 250 preps
UltraClean® Endotoxin-Free Midi Plasmid Prep Kit	12711-10	10 preps
UltraClean® Endotoxin-Free Maxi Plasmid Prep Kit	12611-10	10 preps
UltraClean® Endotoxin Removal Kit	12615	1 kit
UltraClean® Endotoxin-Free Ethanol Precipitation Kit	12616	1 kit
UltraClean® Endotoxin Removal Reagent	12625-25	25 ml
Endotoxin-Free Sodium Chloride	12626-15	15 ml
Endotoxin-Free Centrifuge Tubes	12617-100 12618-50 12619-25	100 each/2 ml tubes 50 each/15 ml tubes 25 each/50 ml tubes
RNA Isolation	Catalog No.	Quantity
PowerBiofilm™ RNA Isolation Kit	25000-50	50 preps
LifeGuard™ Soil Stabilization Solution	12868-10 12868-100 12868-1000 12868-7500	10 ml 100 ml 1 L 7.5 L
On-Spin Column DNase I Kit (RNase-Free)	15100-50	50 preps
Bi Ostic® Stabilized Blood RNA Isolation Kit	12231-20 12231-50 12231-100	20 preps 50 preps 100 preps
Bi Ostic® Blood Total RNA Isolation Kit	12230-20 12230-50	20 preps 50 preps
RNA PowerSoil® DNA Elution Accessory Kit	12867-25	25 preps
RNA PowerSoil® Total RNA Isolation Kit	12866-25	25 preps
UltraClean® Microbial RNA Isolation Kit	15800-50 15800-250	50 preps 250 preps

RNA Isolation ... Continued	Catalog No.	Quantity
UltraClean® Tissue & Cells RNA Isolation Kit	15000-50 15000-250	50 preps 250 preps
UltraClean® Plant RNA Isolation Kit	13300-20 13300-50	20 preps 50 preps
Genomic DNA Isolation	Catalog No.	Quantity
PowerBiofilm™ DNA Isolation Kit	24000-50	50 preps
PowerFood™ Microbial DNA Isolation Kit	21000-50 21000-100	50 preps 100 preps
Bi Ostic® Bacteremia DNA Isolation Kit	12240-50	50 preps
Bi Ostic® FFPE Tissue DNA Isolation Kit	12250-50	50 preps
Bi Ostic® Paraffin Removal Reagent	12251-50	2 x 25 ml
PowerMax® Soil DNA Isolation Kit	12988-10	10 preps
PowerSoil® DNA Isolation Kit	12888-50 12888-100	50 preps 100 preps
PowerSoil®-htp 96 Well Soil DNA Isolation Kit	12955-4 12955-12	4 x 96 preps 12 x 96 preps
UltraClean® Soil DNA Isolation Kit	12800-50 12800-100	50 preps 100 preps
UltraClean®-htp 96 Well Soil DNA Isolation Kit	12896-4 12896-12	4 x 96 preps 12 x 96 preps
UltraClean® Mega Soil DNA Isolation Kit	12900-10	10 preps
PowerClean® DNA Clean-Up Kit	12877-50	50 preps
UltraClean® Fecal DNA Isolation Kit	12811-50 12811-100	50 preps 100 preps
PowerMicrobial® Midi DNA Isolation Kit	12225-25	25 preps
PowerMicrobial® Maxi DNA Isolation Kit	12226-25	25 preps
UltraClean® Microbial DNA Isolation Kit	12224-50 12224-250	50 preps 250 preps
UltraClean®-htp 96 Well Microbial DNA Isolation Kit	10196-4 10196-12	4 x 96 preps 12 x 96 preps
PowerPlant® DNA Isolation Kit	13200-50 13200-100	50 preps 100 preps
UltraClean® Plant DNA Isolation Kit	13000-50 13000-250	50 preps 250 preps
UltraClean®-htp 96 Well Plant DNA Isolation Kit	13096-4 13096-12	4 x 96 preps 12 x 96 preps
UltraClean® Tissue & Cells DNA Isolation Kit	12334-50 12334-250	50 preps 250 preps
UltraClean®-htp 96 Well Tissue DNA Isolation Kit	12996-4 12996-12	4 x 96 preps 12 x 96 preps
UltraClean® Blood DNA Isolation Kit (Non-Spin)	12000-100	100 preps
UltraClean® Blood DNA Isolation Kit (Processes 1,000 ml of Blood)	12000-1000	1 kit
UltraClean® Blood DNA Isolation Kit Plus RNase (Processes 1,000 ml of Blood)	12002-1000	1 kit

Technical Information: Toll free 1-800-606-6246, or 1-760-929-9911 Email: [technical@mobio.com](mailto:technical@mobio.com) Website: [www.mobio.com](http://www.mobio.com)



## Other Quality Products Available from MO BIO Laboratories, Inc.

For more product and detailed information go to [www.mobio.com/catalog-request](http://www.mobio.com/catalog-request) to request a catalog.

Genomic DNA Isolation ...Continued	Catalog No.	Quantity
UltraClean® BloodSpin® DNA Isolation Kit	12200-50 12200-250	50 preps 250 preps
UltraClean®-htp 96 Well BloodSpin® DNA Isolation Kit	12296-4 12296-12	4 x 96 preps 12 x 96 preps
UltraClean® Forensic DNA Isolation Kit	14000-10 14000-20	10 isolations 20 isolations
PowerWater® DNA Isolation Kit	14900-50-NF 14900-50-22 14900-50-45  14900-100-NF 14900-100-22 14900-100-45	50 preps (No filters) (0.22 µm) (0.45 µm) 100 preps (No filters) (0.22 µm) (0.45 µm)
RapidWater™ DNA Isolation Kit	14810-50-NF 14810-50-22 14810-50-45  14810-100-NF 14810-100-22 14810-100-45	50 preps (No filters) (0.22 µm) (0.45 µm) 100 preps (No filters) (0.22 µm) (0.45 µm)
UltraClean® Water DNA Isolation Kit (0.45µm filters)	14800-10 14800-25	10 preps 25 preps
UltraClean® Water DNA Isolation Kit (0.22 µm filters)	14880-10 14880-25	10 preps 25 preps
UltraClean® Water DNA Isolation Kit (No filters)	14800-10-NF 14800-25-NF	10 preps 25 preps
Microbiological Culture Media	Catalog No.	Quantity
TB DRY® Powder Growth Media	12105-05 12105-1 12105-5	500 g 1 kg 5 kg
LB Broth Powder Growth Media, pH 7	12106-05 12106-1 12106-5	500 g 1 kg 5 kg
LB Agar Powder Growth Media, pH 7	12107-05 12107-1 12107-5	500 g 1 kg 5 kg
LB Broth (Lennox) Powder Growth Media, pH 7	12108-05 12108-1 12108-5	500 g 1 kg 5 kg
LB Agar (Lennox) Powder Growth Media, pH 7	12109-05 12109-1 12109-5	500 g 1 kg 5 kg
Soybean-Casein Digest Medium (TSB), USP	12114-05 12114-1 12114-5	500 g 1 kg 5 kg
Soybean-Casein Digest Agar Medium (TSA), USP	12115-05 12115-1 12115-5	500 g 1 kg 5 kg
Yeast Extract	12110-05 12110-1 12110-5	500 g 1 kg 5 kg
Tryptone	12111-05 12111-1 12111-5	500 g 1 kg 5 kg
Agar, Bacteriological Grade	12112-05 12112-1 12112-5	500 g 1 kg 5 kg

Other Reagents and Lab Accessories	Catalog No.	Quantity
20 bp DNA Ladder	17020-40	40 µg
100 bp DNA Ladder	17100-40	40 µg
1 kb DNA Ladder	17200-100	100 µg
UltraClean® Agarose, Molecular Biology Grade	15003-50 15003-100 15003-500 15003-1000	50 g 100 g 500 g 1 kg
UltraClean® MS-8 Agarose	15515-50 15515-100 15515-500	50 g 100 g 500 g
UltraClean® Forensic Agarose	15505-50 15505-100 15505-500	50 g 100 g 500 g
UltraClean® Low Melt Agarose	15005-50 15005-100 15005-500	50 g 100 g 500 g
UltraClean® Low Melt Sieve Agarose	15004-50 15004-100 15004-500	50 g 100 g 500 g
Ethidium Bromide Solution	15006-1 15006-10	1 ml 10 ml
Ethidium Bromide Destaining Tea Bags	15007-25	25 bags
Bromophenol Blue Gel Loading Buffer	15008-1 15008-5	1 ml 5 x 1 ml
Bromophenol Blue/Xylene Cyanol Gel Loading Buffer	15009-1 15009-5	1 ml 5 x 1 ml
TAE Buffer, 50X (Tris-acetate-EDTA)	15001-100 15001-500 15001-1000	100 ml 500 ml 1 liter
TBE Buffer, 10X (Tris-borate-EDTA)	15002-100 15002-500 15002-1000	100 ml 500 ml 1 liter
RNase-Free Gloves	1555-XS 1555-S 1555-M 1555-L	bag of 100 bag of 100 bag of 100 bag of 100
UltraClean® Lab Cleaner	12095-250  12095-500  12095-1000	250 ml squeeze bottle 500 ml spray bottle 1 liter bottle
KAPA PROBE FAST qPCR Kits	51220-100 51220-500 51220-1000	100 reactions 500 reactions 1000 reactions
KAPA SYBR® FAST Universal 2X qPCR Master Mix	51230-100 51230-500 51230-1000	100 reactions 500 reactions 1000 reactions
KAPA2G Robust HotStart ReadyMix	51240-100 51240-500	100 reactions 500 reactions



## Other Quality Products Available from MO BIO Laboratories, Inc.

For more product and detailed information go to [www.mobio.com/catalog-request](http://www.mobio.com/catalog-request) to request a catalog.

Other Reagents and Lab Accessories... <i>Continued</i>	Catalog No.	Quantity
KAPA HiFi HotStart ReadyMix	51250-100 51250-500	100 reactions 500 reactions
KAPA2G FAST HotStart DNA Polymerase with dNTPs	51260-100 51260-250 51260-500	100 reactions 250 reactions 500 reactions
KAPA2G FAST HotStart ReadyMix	51270-100 51270-500	100 reactions 500 reactions
KAPA Long Range HotStart DNA Polymerase with dNTPs	51280-100 51280-250 51280-500	100 reactions 250 reactions 500 reactions
KAPA Taq Polymerase ReadyMix	51290-250	250 reactions
OmniTaq™ DNA Polymerase Enzyme	1224-250	250 reactions (10 U/μl)
OmniTaq™ DNA Polymerase 2x Master Mix	1226-250	250 reactions (5 x 1.25 ml/tube)
Omni KlenTaq™ DNA Polymerase Enzyme	1225-250	250 reactions (25 U/μl)
Omni KlenTaq™ DNA Polymerase 2x Master Mix	1227-250	250 reactions (5 x 1.25 ml/tube)
DNase (RNase-Free)	15600-5 15601-100	5 mg 2500 units
Proteinase K	1223-100 1222-2	100 mg 2 ml (20 mg/ml)
Ribonuclease A (25 mg/ml)	1202-1 1202-5	1 ml 5 ml
PCR Water	17000-1 17000-5 17000-10 17000-11	1 ml 5 x 1 ml 10 x 1 ml 10 ml bottle
Molecular Biology Grade Water	17012-200 17012-5200	200 ml 5 x 200 ml
DEPC Treated Water	17011-200 17011-5200	200 ml 5 x 200 ml
Endotoxin-Free Water	17013-10 17013-50 17013-100 17013-500	10 ml 50 ml 100 ml 500 ml
<b>Instrumentation and Accessories</b>	<b>Catalog No.</b>	<b>Quantity</b>
PowerLyzer™ 24 Bench Top Bead-Based Homogenizer (110/220V)	13155	1 unit
PowerLyzer™ Tube Holder	13156	1 unit
PowerLyzer™ Tube Holder Stand	13157	1 unit
PowerVac™ Mini System	11992	1 unit + 20 adapters
PowerVac™ Manifold	11991	1 unit
PowerVac™ Mini Spin Filter Adapters	11992-10 11992-20	10 adapters 20 adapters
Ceramic Bead Tubes, 1.4 mm	13113-50	50 bead tubes
Ceramic Bead Tubes, 2.8 mm	13114-50	50 bead tubes

Instrumentation and Accessories... <i>Continued</i>	Catalog No.	Quantity
Glass Bead Tubes, 0.5 mm	13116-50	50 bead tubes
Glass Bead Tubes, 0.1 mm	13118-50	50 bead tubes
Metal Bead Tubes, 2.38 mm	13117-50	50 bead tubes
2.0 ml Tough Tubes with Cap	13119-500 13119-1000	500 1000
Carbide Bead Tubes, 0.25 mm	13121-50	50 x 0.5 ml tubes
Garnet Bead Tubes, 0.15 mm	13122-50	50 x 0.5 ml tubes
Garnet Bead Tubes, 0.70 mm	13123-50	50 x 2 ml tubes
Garnet + ¼ Ceramic 15 ml Bead Tubes, 0.70 mm	13134-50	50 tubes
Garnet + ¼ Ceramic 50 ml Bead Tubes, 0.70 mm	13144-10 13144-50 13144-100 13144-500	10 tubes 50 tubes 100 tubes 500 tubes
Glass 15 ml Bead Tubes, 0.1 mm	13135-50	50 tubes
Glass 50 ml Bead Tubes, 0.1 mm	13145-10 13145-50 13145-100 13145-500	10 tubes 50 tubes 100 tubes 500 tubes
Glass 15 ml Bead Tubes, 1.0 mm	13136-50	50 tubes
Ceramic 15 ml Bead Tubes, 1.4 mm	13137-50	50 tubes
Ceramic 50 ml Bead Tubes, 1.4 mm	13147-10 13147-50	10 tubes 50 tubes
Metal 50 ml Bead Tubes, 2.38 mm	13149-10 13149-50	10 tubes 50 tubes
PowerMix 15 ml Bead Tubes	13138-50	50 tubes
PowerMix 50 ml Bead Tubes	13148-10 13148-50	10 tubes 50 tubes
2 ml Collection Tubes	1200-100-T 1200-150-T 1200-250-T	100 tubes 150 tubes 250 tubes
2 ml Screw Cap Tubes	12800-200-E	200 tubes & caps
15 ml Collection Tubes	12700-T	25 tubes
50 ml Centrifuge Tubes	12600-T	25 tubes
Spin Filters (in 1.9 ml tubes)	1200-50-SF 1200-100-SF 1200-250-SF	50 filters 100 filters 250 filters
Endotoxin-Free Centrifuge Tubes	12617-100 12618-50 12619-25	100 each/2 ml tubes 50 each/15 ml tubes 25 each/50 ml tubes
15 ml Midi Spin Filters	12700-SF	25 spin filters



